

T6

Quick Start Guide

1 Packing list

USE Guide

- 1M Micro 5P cable
- 1M 3.5 to 5 audio cable
- 1M Coaxial audio cable
- 1M Optical audio cable

T6

2 Buttons functions

Click: NEXT (TF card)
Long Press: Vol-
Click: PRE (TF card)
Long Press: Vol+
Long Press 4S Turn ON/OFF
Double click, to change Input channel:
COAXIAL-OPTICAL-AUX-TF card
Click: Play/Pause

3 LED, Interface instruction

Power LED
Input channel LED

TF Socket

Connected to TV / PC Headphone audio output
Connected to TV's digital audio out (SPDIF)
DC-5V Power supply
Connected to TV's digital audio out (COAXIAL)

T6

4 Bluetooth use

1, T6 not built on battery. Need to use USB DC-5V power supply, such as phone charger etc.

T6 Transmitter

2, T6 and smart TV are connected by audio cable

A, TV digital audio output is **COAXIAL**, please connect as follows:

T6 Transmitter

TV'S interface

COAXIAL audio cable

T6

B, TV digital audio output is **OPTICAL**, please connect as follows:

T6 Transmitter

Optical audio cable

C, TV is 3.5MM audio output, please connect as follows

T6 Transmitter

TV'S interface

3.5MM Audio cable

T6

3, Press 4S to turn on, the transmitter enters the search and pairing state (Blue LED flashes quickly)

T6 Transmitter

Press > 3S

4, How to pair with Bluetooth headset or Bluetooth stereo (Headset as an example)

1, Turn on the Bluetooth headset and Enter pairing state (Red and Blue LED flash)
2, Distance < 1 M Wait for automatic pairing.
3, After the pairing is completed, one of the LED is always on

5, Change input channel

T6 Transmitter

Double click: change input channel

Coaxial Optical TF card 3.5MM earphones

According to the connection method with the TV, switch to the corresponding indicator light. If you need to transmit the audio of the TF card, switch the light to the TF card

T6

6, TV settings, some TV need to set audio output, different TV have subtle differences

A, T6 and TV are connected via **COAXIAL** cable, please refer to the following settings

1, Press
2, Sound
3, Output device
4, COAXIAL Format: PCM

B, T6 and TV are connected via **OPTICAL** cable, please refer to the following settings

1, Press
2, Sound
3, Speaker
4, External speaker

C, T6 and TV are connected via **3.5MM** audio cable, please refer to the following settings

1, Press
2, Sound
3, Speaker
4, Headphones

T6

7, If the TV still has external sound, press mute

5 TF card music Transmit

T6 supports transmitting audio from TF card to Bluetooth headset or Bluetooth speaker

1. Pair the transmitter with a Bluetooth headset / Bluetooth speaker
2. Insert the TF card in the correct direction, support 64GB capacity, Audio format: SBC Flac MP3 WAV WMA APE, Not supported: AAC format

T6 Transmitter

3, When the TF card is inserted, the input channel LED automatically jumps to the TF card, Double-clicking the T6 middle button can change the input channel

6 LED Instruction

Work mode	LED Status
Power OFF	RED Flashes
Pairing	Blue Flashes
Paired	Blue on

T6

7 Parameter

Bluetooth version: 5.0
Bluetooth protocol: A2DP
Frequency range: 2.402GHz-2.480GHz
Frequency response: 100Hz-20kHz
Transmission distance: 10 M
Connect device: 1
SNR: >90dB
Dimensions: (LxWxH): 90.8x69x23.8 (mm)

8 Warning

1. Please do not strike, disassemble, or puncture the device at will. Do not use in water, moisture, exposure, high temperature environment to prevent malfunction or fire
2. Please do not use this equipment in the places that are not allowed by the national regulations
3. Do not throw this product into water or other liquids or fire, otherwise it will cause permanent damage